

# **ServoMaster: Metadata: controller/protocol/serial/speed**

## **Table of contents**

1 Definition.....	2
-------------------	---

## **1. Definition**

---

`controller/protocol/serial/speed` *property* returns the port speed, in baud.

This is an immutable property - most controllers won't allow you to change the baud rate as soon as it is established.