

ServoMaster: Metadata: servo/precision

Table of contents

1 Definition.....	2
-------------------	---

1. Definition

`servo/precision` *property* contains the number of physical steps available between logical 0.0 and 1.0 positions.

Please note that this property may be dynamic for some controllers, for example [QuadServo](#), [AdvancedServo](#), and [Pololu](#) family.

As a rule of thumb, if the [servo/range/min](#) and [servo/range/max](#) properties are writeable, this property's value may dynamically change.