## ServoMaster: Metadata: controller/protocol/serial/speed

<b>Table of contents</b>		

## 1. Definition

controller/protocol/serial/speed *property* returns the port speed, in baud.

This is an immutable property - most controllers won't allow you to change the baud rate as soon as it is established.